Prewire for Models 304-S12, 401-S12, 411-S12, 1088

Prewire for all “Pan”, “TES”, ‘’Vik”, “Elan”, etc.



Note on Camera Cable : Use one Cat5 cable for Video if balun is used (Holovision P/N 9107)

Or use Coax + Low voltage Power.

NOTE:
Wires shown in red are the minimum required

Wires shown in blue are recommended

Wire for gate release from phone system is required, but it can ben be a spare pair from Cat5/6

NOTE: Low voltage cable requirements include:

1. Telephone relay out - wires from phone system to gates (drive gate and pedestrian gate)
2. Release button (exit button)
3. 2 conductors 16/18 gauge for electric strike

This document is property of Holovision, and may not be reproduced without permission.

Prewire for Model 304-A, 304-W, 401-A, 401-W



Note on Camera Cable : Use one Cat5 cable for Video if balun is used (Holovision P/N 9107)

Or use Coax + Low voltage Power.

NOTE:
Wires shown in red are the minimum required

Wires shown in blue are recommended

Wiegand Keypads:

Cable Distance
Wiegand or Clock-and-Data interface: 500 feet
Recommended cable
Alpha 1295, Belden 5503FE 5 conductor, 22 AWG stranded with overall shield or equivalent

ASCII Keypads:

Cable Distance
ASCII controller: 500 feet
Recommended cable
Cat 5, Cat 6

This document is property of Holovision, and may not be reproduced without permission.

Prewire for Models 304-S12, 401-S12, 411-S12, 1088

Prewire for VIO



NOTE:
Wires shown in red are the minimum required

Wires shown in blue are recommended

This document is property of Holovision, and may not be reproduced without permission.

Prewire for Model 304-A, 304-W, 401-A, 401-W, 1088

Prewire for VIO



NOTE:
Wires shown in red are the minimum required

Wires shown in blue are recommended

Wiegand Keypads:

Cable Distance
Wiegand or Clock-and-Data interface: 500 feet
Recommended cable
Alpha 1295, Belden 5503FE 5 conductor, 22 AWG stranded with overall shield or equivalent

ASCII Keypads:

Cable Distance
ASCII controller: 500 feet
Recommended cable
Cat 5, Cat 6

This document is property of Holovision, and may not be reproduced without permission.

Door Station Rough-in

Model 201, 203, 401, 411, 1088



NOTE: All dimensions given are relative to “finished” surface, not rough grade.

This document is property of Holovision, and may not be reproduced without permission.

Installation Details - 300 and 600 Series



Installation on smooth wall



Installation on stone wall

This document is property of Holovision, and may not be reproduced without permission.

Installation Details - 2 Piece Gooseneck



ROUGH-IN BRACKET INSTALLATION



DETAIL OF ATTACHMENT OF POLE ONTO BASE

This document is property of Holovision, and may not be reproduced without permission.

Installation Details - 2 Piece Gooseneck

Optional application with 2 conduits



NOTE: BE SURE BOTH CONDUITS ARE POINTED IN THE DIRECTION THAT WILL MINIMIZE THE USE OF ELBOWS!

This document is property of Holovision, and may not be reproduced without permission.